

Model No. HG3 MA605 ATTAIN FITNESS Fitness Authority Industrial Co., LTD.
No. 15, Xiangxue Rd., Dali Dist.,
Taichung City 41275, Taiwan.

Congratulations and Thank You!

Thank you for selecting the *ATTAIN FITNESS HG3 MULTI GYM*. The *ATTAIN FITNESS HG3* offers an impressive array of strength training exercises to develop every major muscle group of the body. Whether your goal is cardiovascular fitness, a shapely, toned body or dramatic muscle size and strength, the *ATTAIN FITNESS HG3* will help you achieve the results you want. For your safety and benefit, read this manual and the accompanying literature before using the *ATTAIN FITNESS HG3*. Keep this manual for future reference. If you have additional questions, please call your local *ATTAIN FITNESS* dealer.

www.attainfitnessusa.com

Important Safety Notes


There is a risk assumed by individuals who use this type of equipment. Before beginning this or any other exercise program consult your physician. This is especially important for individuals over the age of 35 or persons with preexisting health problems. ATTAIN FITNESS assumes no responsibility for personal injury or property damage sustained by or through use of this product.

- 1. This product must be assembled on a flat, level surface to assure its proper function.
- 2. Clean pads and frame on a regular basis. ATTAIN FITNESS recommends warm, soapy water. Do not use harsh or abrasive chemicals.
- 3. Inspect and tighten all parts before every use. Replace any worn parts immediately. Failure to do so may result in serious injury.
- 4. Keep children away from the ATTAIN FITNESS HG3 at all times.
- 5. Keep your hands away from cables and pulleys during operation.
- 6. Keep your hands away from moving parts other than the designated handles.
- 7. When adjusting the seat, make sure the spring pin is fully engaged. If not, the seat may slip and cause serious injury.
- 8. Make certain all cables are seated within the pulleys before every use.
- 9. Exercise with care to avoid injury.
- 10. If you are unsure about the proper use of the ATTAIN FITNESS HG3, call your local ATTAIN FITNESS dealer.

QUESTIONS?

As a quality exercise equipment supplier, we are committed to your complete satisfaction. If you have questions, or find missing or damaged parts, we will guarantee your complete satisfaction through our authorized dealer service centers or our home office customer service department. Please call your local dealer for assistance or ATTAIN FITNESS at +1 877-551-7484 and info@attainfitnessusa.com.

www.attainfitnessusa.com




Recommended Tools for Assembly

Ratchet
9/16" Socket
3/4" Socket
9/16" Combination Wrench
3/4" Combination Wrench
Adjustable Wrench
Rubber Mallet
Metric Allen Key Set
Silicone Spray
Window Cleaner or Water

Important Notes and Tips:


- 1. Do not tighten any bolts until instructed.
- 2. Two people are required for the safe assembly of the gym.
- 3. Use window cleaner or water to assist with roller pad installation.
- 4. Use silicone lubricant on guide rods prior to weight plate installation.
- 5. Carefully install plastic caps using a rubber mallet.
- 6. For your convenience, rulers are displayed throughout this manual.
- 7. When measuring bolt lengths, only measure the shank.



HG3 PARTS LIST 1




NOTE: If you are missing a listed part, it likely has been pre-installed in the factory for quality control purposes. Please continue with assembly.



HG3 PARTS LIST 2



NOTE: If you are missing a listed part, it likely has been pre-installed in the factory for quality control purposes. Please continue with assembly.




HG3 PARTS LIST 3




NOTE: If you are missing a listed part, it likely has been pre-installed in the factory for quality control purposes. Please continue with assembly.

| NO. | DESCRIPTION | QTY. |
|-----|----------------------------------|------|
| 129 | 1/2" X 5" HEX BOLT | 2 |
| 130 | 1/2" X 3-1/4" HEX BOLT | 6 |
| 131 | 1/2" X 2-3/4" HEX BOLT | 1 |
| 132 | 3/8" X 5-3/4" HEX BOLT | 1 |
| 133 | 3/8" X 5-1/4" HEX BOLT | 1 |
| 134 | 3/8" X 1-3/4" HEX BOLT | 16 |
| 135 | 3/8" X 1-3/4" HEX THREADED BOLT | 2 |
| 137 | 3/8" X 1" HEX THREADED BOLT | 4 |
| 140 | -, | 5 |
| 142 | 3/8" X 2-3/4" HEX BOLT | 2 |
| 144 | | 2 |
| 145 | 3/8" X 1" ROUND INNER ALLEN BOLT | 2 |
| 147 | M6 X 12L MALE SCREW | 28 |
| 148 | 3/8" X 2" HEX HEAD BOLT | 1 |
| 150 | | 8 |
| 151 | | 4 |
| 153 | M5 X 63L SCREW | 1 |
| 155 | | 2 |
| 156 | TOP PLATE BOLT | 1 |
| 160 | 1/2" LARGER WASHER | 2 |
| 161 | | 12 |
| 163 | 3/8" X 23mm WASHER | 10 |
| 165 | | 8 |
| 169 | 1/2" NYLA-NUT | 9 |
| 170 | | 22 |
| 172 | | 2 |
| 176 | | 12 |
| 185 | 1/4" WASHER | 4 |




When measuring bolt lengths, only measure the shank.




STEP 1 ASSEMBLE MAIN FRAME



TO EASE THE ASSEMBLY PROCESS. DO NOT TIGHTEN ANY BOLTS UNTIL INSTRUCTED.



STEP 2 TOP FRAME AND WEIGHT STACK ASSEMBLY




STEP 3 ASSEMBLE CABLE ARM

 $\overline{\mathbb{A}}$

Remember to keep all BOLTS loose to ensure the holes will align easily.

1. Attach the CABLE ARM ASSEMBLY (18) to the MAIN FRAME (1), using two 1/2" X 3-1/4" HEX BOLTS (130) four 1/2" SMALLER WASHERS (161) and two 1/2" NYLA-NUTS (169).

2. Attach CABLE ARM ASSEMBLY (18) to the CABLE ARM CONNECTOR (19), using two 3/8" X 1" HEX THREADED BOLTS (137) and two 3/8" X 23mm WASHERS (163). Then attach the CABLE ARM CONNECTOR (19) to FRONT UPRIGHT (3), using one 1/2" X




STEP 4 LEG EXTENSION AND SEAT ASSEMBLY

TIP! TO EASE THE ASSEMBLY PROCESS, spray window cleaner or water into the holes of the FOAM ROLLERS (40) before sliding onto shafts.

- 1. Attach the R and L LEG EXTENSION ARMS (21R & 21L) along with RATCHET (32) to the *preassembled* LEG EXTENSION ASSEMBLY (20) as shown. Secure by *tightening* both of the *preinstalled* 5/16" X 5/8" SET SCREW (191), one located in the RATCHET (32) and one in the R LEG EXTENSION ARM (21R).
- Slide a PLASTIC CAP (104) (domed side first) and FOAM PAD (65) onto each side LEG EXTENSION ARMS (21R & 21L), and secure with ALUMINUM CAPS (105) and 5/16" X 1-1/4" COUNTER ALLEN BOLTS (149) on each side. *Tighten*.
- 3. Insert and center the 1" FOAM ROLLER HOLDER (40) into the LEG EXTENSION ASSEMBLY (20). Tighten the two preinstalled 5/16" X 1/2" SET SCREWS (157). Slide a PLASTIC CAP (104) (domed side first) and FOAM PAD (65) onto each side 1" FOAM ROLLER HOLDER (40), and secure with ALUMINUM CAPS (105) and 5/16" X 1-1/4" COUNTER ALLEN BOLTS (149) on each side. *Tighten*.
- 4. NOTE! For this step. The seat pad has two sets of holes. Use the first and third holes from the REAR of the SEAT PAD (63). Attach the SEAT PAD (63) to the SEAT ADJ. HANDLE (11), using two 3/8" X 1-3/4" HEX THREADED BOLTS (135) and two 3/8" X 23mm WASHERS (163). Attach the SEAT ADJ. FRAME (12) to the SEAT ADJ. HANDLE (11) using two SPECIAL 3/8" X 1" ROUND INNER ALLEN BOLTS (145). Tighten both sets of bolts.
- 5. Insert the SEAT SPRING (99) into the MAIN FRAME (1), then slide the SEAT ADJ. FRAME (12) over top of the SEAT SPRING (99) and into the MAIN FRAME (1). You may need to loosen the pre-installed TIGHTEN KNOB (127) to allow the SEAT ADJ. FRAME (12) into the MAIN FRAME (1).

TIP! You can use **TIGHTEN KNOB** (127) to eliminate play in the seat after you have adjusted the seat to the desired height.

- 6. See Figure 1. Remove one of the two small nuts on the loose end of the LONG CLUTH CABLE (71). Simultaneously slide the small threaded shaft through the opening in the L-Bracket welded to the MAIN FRAME (1) and completely thread and tighten the large Pop-Pin into the Barrel welded to the Seat Post Receiver. To start threading to get the pin to seat into one of the holes in the SEAT ADJ. HANDLE (11). Reinstall and tighten the small nut removed from the beginning of the step.
- 7. Slide a PLASTIC CAP (104) (domed side first) and FOAM PAD (65) onto each side of the 1" shafts welded to the SEAT ADJ. HANDLE (11), and secure with ALUMINUM CAPS (105) and 5/16" X 1-1/4" COUNTER ALLEN BOLTS (149) on each side. Tighten.




STEP 5 PRESS ARM ASSEMBLY

- 1. Secure the PLASTIC COVER (74) to the front of the PRESS ARM SUPPORT (9) using one M5 X 63L SCREW (153). Attach the PRESS ARM SUPPORT (9) to the TOP FRAME (4) by aligning the holes and inserting the AXLE (35). Secure and tighten using two 1/2" LARGER WASHERS (160) and two 1/2" NYLA-NUTS (169). Cap with two 1/2" CAP NUTS (103).
- 2. Attach the PRESS ARM (7) to the PRESS ARM SUPPORT (9) by aligning the holes and inserting the PRESS ARM AXLE (38). The LONGER POP PIN (125) should seat into one of the adjustment holes in the PRESS ARM SUPPORT (9). Secure the PRESS ARM AXLE (38) by tightening the preinstalled 5/16" X 1/4" SET SCREW (158).


IMPORTANT! The washer arrangement in the next step is very important to prevent cracking of the PRESS ARM PANEL (56). DO NOT OVERTIGHTEN!

3. Attach the PRESS ARM PANEL (56) to the PRESS ARM (7) using four 1/4" WASHERS (185), eight SMALL SEALING RINGS (184) and four M6 X 12L MALE SCREWS (147). Install two OVAL PLUGS (102) into the bottom of the PRESS ARM (7) using a rubber mallet.



STEP 6 SEAT BACK ADJUSTER AND LEG HOLDER ASSEMBLY

- 1. Attach the SEAT BACK ADJUSTER (13) to the FRONT UPRIGHT (3), using one 3/8" X 5-1/4" HEX BOLT (133), two 3/8" LARGER WASHERS (163) and one 3/8" NYLA-NUT (170). Tighten this bolt until the SEAT BACK ADJUSTER (13) is snug against the FRONT UPRIGHT (3) to eliminate play. NOTE! If it does not pivot FREELY, loosen slightly.
- Attach the LEG HOLDER (14) (holes facing down), to the SEAT BACK ADJUSTER (13) using three 5/16" X 1/2" SCREWS (150) and two 5/16" WASHERS (165). Tighten.



STEP 7 INSTALL TOP CABLE



On the following pages, when references are made regarding the LEFT, RIGHT and FRONT of the machine, the directions are as if you are seated in the gym with your back against the Back Pad.


Assemble cables and pulleys simultaneously.

- 1. See Fig. 1 Insert the **Bolt-end** of the **TOP CABLE (82)** through the bottom of the front slot of the TOP FRAME (4), then over Pulleys T1 and T2 as shown. Secure each pulley using one 3/8" X 109.5L FLAT PIN BOLT (140) and one M6 X 12L MALE SCREW (147). *Tighten.* **NOTE!** The cable runs above the **TOP FRAME (4)**, *NOT* inside the tube.
- 2. See Fig. 2 Countinue routing the cable entering the top and exiting on bottom of the **Left** Side Pulley T3 mount to the PRESS ARM SUPPORT (9) using one 3/8" X 2-3/4" HEX BOLT (142) and one 3/8" NYLA-NUT (170). DO NOT Tighten. Route cable around Pulley **T4** mounted on the **FRONT UPRIGHT (3)** by entering the bottom and exiting the top. Secure using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). Tighten.
- 3. See Fig. 3 Route the cable around **Right Side Pulley T5** mounted in the **PRESS ARM SUPPORT** (9), by entering the top and exiting the bottom. *Tighten*.
- 4. See Fig. 4 Route the cable under Pulley T6 and mount in the slot in the FRONT UPRIGHT (3) using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). Continue to route the cable over Pulley T7 and mount to the top rear of the FRONT UPRIGHT (3) using one 3/8" X 109.5L FLAT PIN BOLT (140) and one M6 X 12L MALE SCREW (147). Tighten.
- 5. See Fig. 5 Install a 4-1/2" PULLEY (100) into each of the ADJ. PULLEY BLOCKS (23) in the second hole below the welded stop plate. (DO NOT TIGHTEN. You may need to move the pulleys when adjusting the cables).
- 6. See Fig. 6 & 7 Route the cable over **Pulleys T9** and **T11** mounted to the **TOP FRAME (4)** while simultaneously routing the cable under the installed **Pulleys T8** and **T10** mounted in the ADJ. PULLEY BLOCKS (23). (NOTE! The ADJ. PULLEY BLOCKS (23) do not attach to the frame, they are held in place by the cable). Secure Pulley T9 using one 3/8" X 2-3/4" Hex Bolt (142) and one 3/8" NYLA-NUT (170) and Pulley T11 using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). Tighten Bolts at T9 and T11.
- 7. See Fig. 8 Secure the **TOP CABLE (82)** by threading the **Bolt-end** at least a third of the way into the TOP PLATE ASSEMBLY (58). Tighten Jam-nut on the Bolt-end against the **TOP PLATE ASSEMBLY (58).**
- 8. Top Cable Adjustment. There are multiple adjustment points. Remove cable slack by adjusting the two preinstalled 1/2" STOPPERS (93) down onto the plates welded to the top of the ADJ. PULLEY BLOCKS (23) equally to remove all cable slack. If the slack cannot be completely removed, adjust one or both pulleys located in the ADJ. PULLEY BLOCKS (23) down one or move holes or adjust the Bolt-end of the cable in the TOP PLATE ASSEMBLY (58).



The **Bolt-end** must be at least a 1/3 into the **TOP PLATE ASSEMBLY (58)**. Tighten the Jam-nuts located on both 1/2" STOPPERS (93). Tighten the pulleys located in both ADJ. PULLEY BLOCKS (23).

STEP 7 INSTALL TOP CABLE



STEP 8 INSTALL AB CRUNCH CABLE






Bolt-end

AB CRUNCH CABLE (83)

REMOVABLE END (83A)

- 1. See Fig. A1 Screw the **Bolt-end** of the **AB CRUNCH CABLE (83)** at least one-third of the way into the threaded receptor welded to the **TOP FRAME (4)**. This **Bolt-end** is an adjustment point if needed once all of the cables have been installed. **Be sure to tighten the Jam-nut.**
- 2. See Fig. A2 Install one 4-1/2" PULLEY (100) into SINGLE PULLEY BLOCK (24) using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). *Tighten*. Route the cable down to Pulley A2.
- 3. See Fig. A3 Install one 4-1/2" PULLEY (100) into the second hole up of ADJ. PULLEY BLOCK (23) and secure with one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). *Tighten*. Continue routing the cable up to the Pulley A3.
- 4. See Fig. A4 Install one 3-1/2" PULLEY (101) into the CABLE ARM CONNECTOR (19), using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). *Tighten*. Continue routing the cable down to the Pulley A4.
- 5. See Fig. A5 Install one 4-1/2" PULLEY (100) into the FRONT UPRIGHT (3), using one 3/8" X 109.5L FLAT PIN BOLT (140) and one M6 X 12L MALE SCREW (147). Tighten. Continue routing the cable up to and over the top of Pulley A5. Install REMOVABLE END (83A) at A5. IMPORTANT! Make sure it is completely tightened!



STEP 9 INSTALL LEG EXTENSION CABLE




Threaded End

LEG EXTENSION CABLE (84)

Steel Ball End


1. See Fig. E1 & E2 Hook the steel ball end of the LEG EXTENSION CABLE (84) into the groove in the LEG CURL CAM (22), and then route the cable in between two Pulleys E2 and E3 and secure using one 3/8" X 75L FLAT PIN BOLT (141), four 3/8" SMALLER WASHERS (164) and one M6 X 12L MALE SCREW (147) each, as shown in FIG STEP 1. Continue routing cable down and around Pulley E4 mounted in a slot in the front of the MAIN FRAME (1) using one 3/8" X 75L FLAT PIN BOLT (141) and one M6 X 12L MALE SCREW (147).

2. See Fig. E5,E6 & E7 Route the cable down around **Pulley E5** mounted under the **SEAT ADJ.** FRAME (12), and secure using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT



(170). Route the cable around Pulley E6 mounted under rear part of the MAIN FRAME (1) and secure using one 4-1/2" PULLEY (100), one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). Screw the threaded bolt-end into the SINGLE PULLEY BLOCK (24).

Note: The Threaded end is an adjustment point. It should be threaded in a minimum of one third of the way into the SINGLE PULLEY




STEP 10 INSTALL CONNECT CABLE



Threaded End CONNECT CABLE (85) Threaded End

- 1. See Figs. C1 & C2 Screw the threaded end of CONNECT CABLE (85) into the SINGLE PULLEY BLOCK (24) and route the cable up and over Pulley C2 mounted on TOP FRAME (4), using one 3/8" X 2-3/4" HEX BOLT (142) and one 3/8" NYLA-NUT (170).
- 2. See Fig. C3 Route the cable down and around Pulley C3 mounted on the MAIN FRAME (1), using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170).
- 3. See Fig. C4 Continue to route cable up and around the Pulley C4 mounted at second hole of ADJ. PULLEY BLOCK (23), using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170).




STEP 11 INSTALL CABLE ARM CABLE



1. The CABLE ARM CABLE (86) is preinstalled in the CABLE ARM (16). Mount Pulleys P3 and P7 along with their CABLE RETAINER PLATE (27) to the CABLE ARM ASSEMBLY (18) as shown, using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170). Route cable over top of these pulleys. *Tighten* these nuts, make sure the CABLE RETAINER PLATES (27) do not rub against the cable.

2. Continue routing, on both sides, down and around the Pulleys P4 and P6 mounted to the base of CABLE ARM ASSEMBLY (18) using one CABLE RETAINER PLATE (27), one 3/8" X 5-3/4" HEX BOLT (132), two 3/8" X 23mm WASHERS (163) and one 3/8" NYLA-NUT (170) for each side. Tighten these nuts, making sure the CABLE RETAINER PLATES (27) do not rub against the cable.




STEP 12 INSTALL LOW CABLE





If you have purchased the OPTIONAL LEG PRESS, DO NOT INSTALL the LOW CABLE (87). Follow the instructions in the LEG PRESS box.

- Route the LOW CABLE (87) under Pulley L1 mounted in the front of the FOOT PLATE CONNECTOR (5) using one 3/8" X 45L FLAT PIN BOLT (144) and one M6 X 12L MALE SCREW (147), then go around Pulley L2, using one 3/8" X 45L FLAT PIN BOLT (144) and one M6 X 12L MALE SCREW (147). The cable should run underneath the FOOT PLATE CONNECTOR (5), not inside the tube.
- 2. Continue routing cable up and over Pulley L3 mounted at bottom of DOUBLE PULLEY BLOCK (25), using one 3/8" X 1-3/4" HEX BOLT (134) and one 3/8" NYLA-NUT (170), then down to clip steel ball end to the bracket welded at MAIN FRAME (1).



STEP 13 WEIGHT STACK SHROUDS & ACRYLIC PANELS ASSEMBLY

- 1. Attach the BOTTLE CAGE (68) to the RIGHT WEIGHT SHROUD (46R) using two M5 X 12L SCREWS (155), and two M5 NYLA-NUTS (172). *Tighten*.
- 2. Attach the WEIGHT SHROUD (45), hole oriented toward bottom, to the tabs welded on the REAR STABILIZER (2), and TOP FRAME (4) using four 5/16" X 1/2" SCREWS (150), and four 5/16" WASHERS (165). Then attach LEFT WEIGHT SHROUD (46L) to the tabs welded on the REAR STABILIZER (2), and TOP FRAME (4) using two 5/16" X 1/2" SCREWS (150), and two 5/16" WASHERS (165). The LEFT WEIGHT SHROUD (46L) can be identified by the relief cut along the bottom, and without holes for the Bottle Cage. Then attach RIGHT WEIGHT SHROUD (46R) to the tabs welded on the REAR STABILIZER (2), and TOP FRAME (4), using two 5/16" X 1/2" SCREWS (150), and two 5/16" WASHERS (165).



TIGHTEN ALL BOLTS NOW! Start from the bottom and work up.




IMPORTANT! In the following steps, DO NOT OVERTIGHTEN the acrylic panels. Cracked panels due to overtightening are not covered under the warranty!

- 3. Attach two ACRYLIC PANEL TRIMS (44) to the tabs welded on the FRONT UPRIGHT (3), using four M6 X 70L ROUND SCREWS (151) and four PLASTIC STUDS (115).
- 4. Attach two L PLATES (33) to the RIGHT WEIGHT SHROUD (46R) using one each M6 X 12L MALE SCREW (147) and one each M6 ACORN NUT (176). Attach two L PLATES (33) to the LEFT WEIGHT SHROUD (46L) using one each M6 X 12L MALE SCREW (147) and one each M6 ACORN NUT (176).
- 5. Attach the ACRYLIC PANELS (54L & 54R) to the previously installed L PLATES (33) using M6 X 12L SCREWS (147), SMALL SEALING RINGS (184), and M6 ACORN NUTS (176). Attach these ACRYLIC PANELS (54L & 54R) to the front ACRYLIC PANEL TRIM (44) using M6 X 12L SCREWS (147), SMALL SEALING RINGS (184), and M6 ACORN NUTS (176). The ACRYLIC PANELS should be in front of (covering) the L PLATES, and behind (exposing) the ACRYLIC PANEL TRIM.
 DO NOT OVER TIGHTEN THE SCREWS! CRACKED PANELS DUE TO OVER TIGHTEN ARE NOT COVERED UNDER WARRANTY.
- 6. Attach the TOP ACRYLIC PANELS (55R & 55L) and TOP PANEL TRIM (43) to the TOP FRAME (4) using two M6 X 12L SCREWS (147) and two SMALL SEALING RINGS (184).

 DO NOT OVER TIGHTEN THE SCREWS! CRACKED PANELS DUE TO OVER TIGHTEN ARE NOT COVERED UNDER WARRANTY.




STEP 13 WEIGHT STACK SHROUD




STEP 14 ATTACH ACCESSORIES

- 1. Attach **BOTTLE CAGE (68)** and the **LAT BAR (42)** to **TOP CABLE (82)** and rest on Lat Bar Holder.
- 2. Attach AB CRUNCH STRAP (60) with CLIP (91) to the AB CRUNCH CABLE (83) and MULTIPLE D-RING SINGLE HANDLE (62) to CABLE ARM (16).
- 3. Attach CURL BAR (41) with CLIP (91), CHAIN (73) to the LOW CABLE (87).




The Cable Adjustment of ELITE GYM

- a. The Cables should be tightened to the point just before the Top Plate lifts off the stack. In other words, if the Top Plate is not resting on the stack, you will need to add length, or, if there is slack in the cables, you will need to shorten the cables. There are several adjustment points. If only minor adjustments need to be made, you can adjust the Screw ends on the Top Cable (at the Top Plate), the Low Cable (where it screws into the Pulley Block), or the Bench Press Cable (where it screws into the Pulley Block with Stopper). These ends of these cables must be screwed in at least 1/3 of their length for safety purposes. Once you are done with these adjustments, lock them into place using the jam nuts.
- b. Broader adjustments are made at the Adjustable Pulley Block (23). Moving the bottom pulley toward the center decreases length (takes up slack). Conversely, moving the bottom pulley outward gains cable length.




COMPLETE PARTS CHART NO. DESCRIPTION QTY. MAIN FRAME REAR STABILIZER FRONT UPRIGHT TOP FRAME FOOT PLATE CONNECTOR GUIDE ROD PRESS ARM RIGHT HANDLE OF PRESS ARM LEFT HANDLE OF PRESS ARM PRESS ARM SUPPORT ROTOR OF PRESS ARM SUPPORT SEAT ADJ. HANDLE SEAT ADJ. FRAME SEAT BACK ADJUSTER LEG HOLDER METAL HINGE CABLE ARM SWIVEL CABLE ARM END CABLE ARM ASSEMBLY 8R CABLE ARM CONNECTOR LEG EXTENSION ASSEMBLY 21R RIGHT LEG EXTENSION ARM LEFT LEG EXTENSION ARM LEG CURL CAM ADJ. PULLEY BLOCK SINGLE PULLEY BLOCK DOUBLE PULLEY BLOCK CABLE GUIDE BRACKET CABLE RETAINER PLATE LEVER OF CABLE ARM HANDLE PLATE 21R 21L PIN LEVER HANDLE LEVER **RATCHET** L PLATE LOCKING PLATE **AXLE** THREADED BOLT HANDLE PLATE AXLE PRESS ARM AXLE PRESS ARM HANDLE AXLE TUBE 525L FOAM ROLLER HOLDER CURL BAR LAT BAR TOP PANEL TRIM ACRYLIC PANEL TRIM WEIGHT SHROUD 46R RIGHT WEIGHT SHROUD 46L LEFT WEIGHT SHROUD 46L \ *Parts images are not to scale.



| COMPLETE PARTS CHART | | | | | | | | | | |
|---------------------------------|--|----------|------------|------------|-----|----------|-----|-----|--|--|
| NO. | DESCRIPTION | QTY. | | | | | | | | |
| | RIGHT TRIM OF CABLE ARM | 2 | | م | | | | | | |
| 90L 91 | LEFT TRIM OF CABLE ARM CLIP | 2 6 | 000 | 001 | 01 | W 02 | 02 | 94 | | |
| 91 | CAP FOR CABLE ARM | 2 | 90R | 90L | 91 | 92 | 93 | 94 | | |
| 93 | 1/2" STOPPER | 2 | | | 6 | | | | | |
| 94 | MAIN FRAME STOPPER | 1 | | | | | | | | |
| 95 | NUT FOR LEG EXTENSION | 1 | | 9 | · | 6 | | | | |
| 96 97 | PIN BOLT FOR LEG EXTENSION LEG EXTENSION LARGER SPRING | √ 1 1 | 95 | 96 | 97 | 98 | 99 | 100 | | |
| 98 | LEG EXTENSION SMALLER SPRING | | | | | | _ | 6 | | |
| 99 | SEAT SPRING | 1 | | 1 | | | | | | |
| 100 | 4-1/2" PULLEY (114mm) | 25 | | ~ | | | | | | |
| 101 | 3-1/2" PULLEY (90mm) | 11 | 101 | 1 | 02 | 103 | 104 | 105 | | |
| 102 103 | 40 X 80mm OVAL PLUG 1/2" PLASTIC DOME CAP | 2 4 | | | | | | | | |
| 103 | PLASTIC CAP | 8 | | 0 | | 0 | | | | |
| 105 | ALUMINUM CAP | 8 | | | | | | | | |
| 106 | 1-1/8" ID STEEL BUSHING | 4 | 106 | 107 | 108 | 109 | 110 | 111 | | |
| 107 | 1" ID BUSHING | 2 | | | | | | | | |
| 108 | 3/4" ID BUSHING | 2 | | | | ñ | | | | |
| 109 110 | 1" ID PLASTIC GUIDE ROD HOLDER RUBBER CUSHION | 2 | • | \bigcirc | | U | | | | |
| 111 | BACK PAD STOPPER | 1 | 112 | 113 | 114 | 115 | 116 | 117 | | |
| 112 | BEARING | 2 | | | | | | | | |
| 113 | SEAT PAD SUPPORT STOPPER | 2 | | 0 | | | | | | |
| 114 | STOPPER FOR PRESS ARM HANDLE | 2 | 110 | 110 | 120 | 101 | 122 | 100 | | |
| 115 | PLASTIC STUDS | 4 | 118 | 119 | 120 | 121 | 122 | 123 | | |
| 116 117 | 1" T SHAPE END PLUG 60/28ZZ BEARING | 2 | | \sim | | | | | | |
| 118 | SPACER FOR MAIN FRAME | 4 | | | | | | | | |
| 119 | SPACER FOR CABLE ARM | 4 | 9 | | | | | | | |
| 120 | LARGER SEALING RING | 2 | 124 | 125 | 126 | 127 | 128 | | | |
| 121 | BEARING BASIN | 4 | 144 | 123 | 120 | 147 | 120 | | | |
| 122 | BEARING COVER | 4 | | | | 78 | | | | |
| 123 124 | MAGNET | 4 2 | | | | | | | | |
| 125 | LONGER POP PIN | 1 | 129 | | | 133 | | | | |
| 126 | SHORTER POP PIN | 1 | ∕ ⊅ | | | <i>7</i> | | | | |
| 127 | TIGHTEN KNOB | 1 | | |) | | | | | |
| 128 | SPRING CLIP | 2 | 130 | | | 134 | | | | |
| 129 | 1/2" X 5" HEX BOLT | 2 | | | | | | | | |
| 130 131 | 1/2" X 3-1/4" HEX BOLT 1/2" X 2-3/4" HEX BOLT | 7 1 | | | | | | | | |
| 132 | 3/8" X 5-3/4" HEX BOLT | 1 | 131 | | | 135 | | | | |
| 133 | 3/8" X 5-1/4" HEX BOLT | 1 | ~ | | | | | | | |
| 134 | 3/8" X 1-3/4" HEX BOLT | 16 | | | | | | | | |
| 135 | 3/8" X 1-3/4" HEX THREADED BOLT | 2 | 132 | | | 136 | | | | |
| 136 | 3/8" X 1-1/4" HEX THREADED BOLT | 2 | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| *Parts images are not to scale. | | | | | | | | | | |

COMPLETE PARTS CHART **DESCRIPTION** QTY. NO. 3/8" X 1" HEX THREADED BOLT H 3/8" X 1" INNER HEX SCREW 3/8" X 3/4" INNER HEX SCREW 3/8" X 109.5L FLAT PIN BOLT (A) (1) 3/8" X 75L FLAT PIN BOLT 3/8" X 2-3/4" HEX BOLT 3/8" X 51.5L FLAT PIN BOLT 3/8" X 45L FLAT PIN BOLT (c) 3/8" X 1" ROUND INNER ALLEN BOLT 3/8" X 30.5L FLAT PIN BOLT M6 X 12L MALE SCREW 3/8" X 2" HEX HEAD BOLT 5/16" X 1-1/4" COUNTER ALLEN BOLT 5/16" X 1/2" SCREW M6 X 70L ROUND SCREW M6 X 45L SCREW M5 X 63L SCREW M5 X 18L SCREW M5 X 12L SCREW (8) (1) TOP PLATE BOLT 5/16" X 1/2" SET SCREW 5/16" X 1/4" SET SCREW M6 X 6L SET SCREW 1/2" LARGER WASHER 1/2" SMALLER WASHER 3/8" X 35mm WASHER (WIDE FLANGE) 3/8" X 23mm WASHER 3/8" X 19mm WASHER 5/16" WASHER 1-1/4" NUT 1" NUT (0) 24mm NUT 1/2" NYLA-NUT 3/8" NYLA-NUT M6 NYLA-NUT M5 NYLA-NUT 1/2" NUT 8mm HEX WRENCH 3/8" CAP NUT M6 ACORN NUT 4mm HEX WRENCH 5mm HEX WRENCH 6mm HEX WRENCH 3/8" X 3/4" HEX THREADED BOLT 3/8" THIN NUT 1-1/4" ROUND PLUG (0) 3/8" X 1-1/4" BUTTON HEAD SCREW SMALLER SEALING RING 1/4" WASHER 1" X 60mm ROUND HAND GRIP 1/4" X 1-1/4" SCREW 1/4" WASHER 1/4" NUT 3/8" STOPPER 5/16" X 5/8" INNER HEX SCREW 3/8" X 16mm WASHER *Parts images are not to scale.



Assembly is complete! Please take the following steps before using the gym:

- 1. Make certain all bolts are tightened securely.
- 2. Make certain all cables are seated into all pulley grooves. A cable rubbing against steel will peel the nylon coating, voiding warranty and resulting in a need for replacement.
- 3. Pre-stretch the cables. Put the Weight Selector Pin (75) in the bottom hole on the weight stack. Pull on the cables with great force, helping remove any kinks and providing any initial cable stretch.
- 4. Be aware the cables can loosen and slightly stretch upon initial use.
- 5. The cables should be adjusted as tight as possible, but no so tight as to lift the Top Plate (58) above the weight stack. Be certain to secure the jam nuts after adjustments are made.
- 6. For better performance, apply a household lubricant (such as silicone) to any adjustable areas and to the **Guide Rods** (6).
- 7. Enjoy many years of a Fit Lifestyle.

Thank you for purchasing the ATTAIN FITNESS HG3 MULTI GYM! If you have any questions, please call your local ATTAIN FITNESS dealer. Please contact our customer service department at +1 877-551-7484 and info@attainfitnessusa.com www.attainfitnessusa.com